



Exhibition of motor vehicles at trade fair stands

For reasons of preventive fire protection and general event safety, please note the points below regarding the display of motor vehicles at trade fair stands.

The following applies to all vehicle types:

- The exhibition of motor vehicles must be registered with Messe Frankfurt Venue GmbH, Technical Event Management. Registration takes place as part of the stand approval process. The vehicle type and the number of vehicles to be exhibited must be stated.
- Driving inside the exhibition halls is not permitted. Vehicles must be pushed.
- Suitable extinguishing agents for the respective vehicle must be kept on the trade fair stand in sufficient quantities.
- The rescue card for the respective vehicle must be available at the trade fair stand and sent to Technical Event Management in advance.
- The position of the vehicle within the stand area must be marked on a plan.
- The vehicle must not be started or moved accidentally or negligently.
- The vehicle should be brought into the hall as late as possible before the event and must be registered with the hall manager.
- Demonstrations during the event must be approved by Technical Event Management.
- If available, the "show mode" should be activated on the vehicle.

Vehicles with combustion engines:

- The fuel tank must be largely empty and locked.
- The battery must be disconnected or removed.
- The vehicle can only be powered by the starter battery if it is ensured that no dangerous gases are produced, the contacts are designed to be touch-safe and the starter is permanently disconnected from the battery.

Vehicles with electric or hybrid drives:

- The drive motor must be disconnected from the battery, e.g. using a disconnecter.
- The high-voltage battery must be ensured to be free of voltage or in a non-critical condition typical for batteries.
- Temporary charging processes during the event are only permitted in exceptional cases and must be registered up to six weeks before the start of setup. They must be supervised and may only be carried out with the written approval of Technical Event Management. Please also note the separate information sheet „Temporary charging processes“.



Last updated
21.05.2024

Vehicles with gas and hydrogen drive:

- The pressure vessel must be emptied and depressurized.
- Further information on the use of compressed and liquid gases can be found in point 5.7 of the technical guidelines.

If you have any questions or problems, the staff at Messe Frankfurt Venue GmbH's Technical Event Management (V 31) will be happy to assist you at any time.

They are also your point of contact for any questions pertaining to safety, security and coordination, and are responsible for monitoring compliance with the rules and regulations of Messe Frankfurt.

You will find our technical guidelines for downloading on the Messe Frankfurt website:

<https://www.messefrankfurt.com/frankfurt/en/services.html#guidelines>

If you have any questions, please contact the Technical Event Management

at Messe Frankfurt, telephone +49 69 75 75-59 04, e-mail standapproval@messefrankfurt.com.

We look forward to a fruitful collaboration and wish you a successful event.

Best regards,

Messe Frankfurt Venue GmbH

Technical Event Management